<u>Æ</u> FINN DELUXE

Chic Living Styles

Experience the perfect harmony of style and comfort with modern furnishing

Trendy Tufted

Style. Comfort. Yours.

EXPLORING THE MODERN AND CONTEMPORARY Style, Comfort, and Unbeatable Value

Welcome to Finn Deluxe, your top choice for beautiful furniture and home accessories. We believe that your home should showcase your style.

Our dedication to quality and great design is what sets us apart. Whether you're furnishing your dream home, updating a room, or adding that perfect finishing touch.

From timeless classics to contemporary pieces, we have something to match everyone's taste. Think cozy sofas, elegant dining sets, and eye-catching decor to make your space comfy and stylish.

Browse our collections, imagine the possibilities, and transform your house into a unique reflection of you.

Discover the perfect mix of beauty and practicality with Finn Deluxe. Your dream home is just a click away.

Trendy Tufted

Our Trendy Tufted dining chair: a sleek and minimalist enhancement for your dining room or living room. Upholstered in premium fabrics and moulded foam for optimal comfort and maintaining its shape impeccably. Finished with matte dark brown legs for a touch of refinement, it effortlessly elevates any dining area or living room.



Dining Chairs



Trendy Tufted

901F107

Materials:


Material: Textile Frame: Metal

Back: Moulded Foam Seat : Moulded Foam


Legs: Metal - Finishing: Powder Coated Dark Brown



(cm): W 43 x D 55 x H 80.5 (inch): W 17 x D 22 x H 31.7 Seat Height: 46 cm Seat Depth: 41.5 cm Weight: 9.5 kg



Assembly of the product is required. Rest assured, we've included a comprehensive set of screws and tools within the packaging.





Products Care & Maintenance

Glass Products

Handle glass products carefully to prevent accidental drops and breakage.

Use a soft cloth to clean glass surfaces. Avoid using abrasive cleaners or scrubbing pads, as they can scratch the surface of the glass. Clean glass products with a gentle cleaning solution, such as mild soap and water, or a vinegar and water solution. Avoid using harsh chemicals, as they can damage the glass. Dry glass products thoroughly after cleaning to prevent water spots and streaks. Avoid placing heavy objects on glass surfaces, as they can cause the glass to crack or break.

Protect glass products from direct sunlight, which can cause fading or discolouration.

Store glass products in a safe place to prevent accidental breakage.

Marble Products

Wipe up spills immediately with a soft, dry cloth to prevent staining. Avoid using acidic or abrasive cleaners on marble, as they can scratch or etch the surface.

Use a mild soap and water solution to clean marble surfaces. Avoid using acidic or abrasive cleaners, as they can scratch or etch the surface.

Dry marble surfaces thoroughly after cleaning to prevent water spots.

Use coasters or placemats under drinks and dishes to prevent scratches and stains.

Avoid placing heavy objects on marble surfaces, as they can crack or damage the material.

Protect marble surfaces from direct sunlight and heat sources, which can cause fading or discolouration.

Apply a marble sealer periodically to protect the surface from stains and damage. Be sure to follow the manufacturer's instructions carefully.

Wood

Dust regularly with a soft, dry cloth or use a soft-bristled brush to remove dust from crevices.

Use a damp cloth to wipe up spills immediately and dry the surface with a clean cloth.

Avoid exposing wood furniture to extreme temperatures or humidity, which can cause warping or cracking.

Apply furniture polish or wax periodically to protect the finish and prevent scratches.

Leather

Wipe spills immediately with a clean cloth. For tough stains, use a leather cleaner recommended by the manufacturer. Keep leather furniture away from direct sunlight and heat sources, which can cause fading or cracking.

Use a leather conditioner periodically to keep the material soft and prevent cracking.

Avoid using harsh chemicals or abrasive cleaners on leather.

Fabric

Vacuum fabric furniture regularly to remove dust and debris. Use a fabric cleaner recommended by the manufacturer to remove stains and spills.

Protect fabric furniture from direct sunlight, which can cause fading. Avoid using heat or steam to clean fabric, as this can damage the material.

By following these tips for caring for different types of materials, you can help ensure that your furniture and home accessories stay in great condition for years to come! If you have any questions or concerns about product care, please don't hesitate to contact us. You can reach us by email sales@finndeluxe.co.uk

Velvet Products

Avoid placing velvet products in direct sunlight or near heat sources, as this can cause fading or discolouration.

Use a soft-bristled brush to gently remove dust and debris from velvet surfaces. Do not use a vacuum cleaner, as it can damage the delicate fibres of the velvet.

To remove stains from velvet products, use a gentle cleaning solution such as white vinegar or a specialized velvet cleaner. Test the cleaner on a small, inconspicuous area first to ensure that it does not damage the fabric.

Blot spills immediately with a clean, dry cloth to prevent the liquid from soaking into the fabric.

If your velvet product becomes wet, allow it to air dry naturally. Do not use a hair dryer or heat source to speed up the drying process. If you need to iron velvet, use a low heat setting and place a thin cloth between the velvet and the iron to prevent damage to the fibres.

Store velvet products in a cool, dry place, preferably in a breathable fabric bag or wrapped in acid-free tissue paper.

Metal

Use a soft, damp cloth to remove dust and dirt from metal surfaces. Use a metal cleaner or polish recommended by the manufacturer to remove stains or tarnish.

Avoid using abrasive materials or chemicals that can scratch or damage the metal finish.

Protect metal furniture from exposure to moisture, which can cause rust or corrosion.

Ceramic

Use a soft cloth or sponge to clean ceramic surfaces.

For tough stains, use a mild soap and water solution.

Avoid exposing ceramic items to extreme temperatures, as this can cause cracking or breakage.

Protect ceramic items from impacts or rough handling, as they can be fragile.

Artificial leather Products

Wipe down artificial leather products with a damp cloth to remove dust and dirt. For more stubborn stains, use a mild soap and water solution.

Avoid using harsh chemicals or cleaners, as they can damage the material.

If your artificial leather product becomes wet, wipe it down with a dry cloth and allow it to air dry naturally. Do not use a heat source or hair dryer to speed up the drying process.

Avoid placing artificial leather products in direct sunlight or near heat sources, as this can cause fading or cracking.

To prevent scratches and damage, avoid placing sharp or heavy objects on artificial leather surfaces.

Store artificial leather products in a cool, dry place, preferably in a breathable fabric bag or wrapped in acid-free tissue paper.

Rattan Baskets

Dust Regularly: Wipe with a dry cloth to remove dust. Gentle Cleaning: Use a damp cloth with mild detergent for deeper cleaning. Avoid excessive moisture.

Protect from Sun: Keep away from direct sunlight to prevent fading. Avoid Water: Protect from spills and dry if it gets wet. Handle with Care: Avoid sharp objects to prevent scratches. Rotate Contents: Rearrange items inside to ensure even wear. Consider Liners: Use liners for items that may damage the rattan. Store in Humidity: In humid climates, store in a dry place when not in

use. Repair if Needed: Fix loose or damaged rattan to prevent further issues.

Terms and Conditions of 2-Year Guarantee:

Coverage Period:

The 2-Year Guarantee applies to all other products, such as chairs, stools, mirrored furniture, ceramic vases, tables, and glass, covering any structural faults discovered. Upholstered chairs and stools are included with coverage for frames, joints, webbing, and springs. However, fabrics and foam fillings are excluded from the guarantee, as they may experience general wear and tear.

Eligibility:

The guarantee applies to the original purchaser of the products and is non-transferable.

Scope of Coverage:

The guarantee covers defects in materials and workmanship under normal use and care.

Damage resulting from misuse, abuse, negligence, or accidents is not covered.

Conditions for Coverage:

The furniture must be used in accordance with provided care and usage instructions.

Any modifications or alterations to the furniture by parties other than the manufacturer or authorized personnel void the guarantee. Notification of Defects:

Any defects or issues covered by this guarantee must be reported to us within a reasonable timeframe.

Repair, Replacement, or Refund:

In the event of a covered defect, the retailer or manufacturer reserves the right to choose between repairing the furniture, providing a replacement, or offering a refund.

Exclusions:

This guarantee does not cover normal wear and tear, fading, or changes in appearance over time.

Damages caused by improper assembly, installation, or maintenance are not covered.

Professional Inspection:

The retailer or manufacturer may require inspection by authorized personnel to assess the nature of the defect before initiating repairs, replacement, or a refund.

How to Claim & Proof of Purchase:

If you encounter any issues with the warranty, simply contact our Customer Service team at [sales@finndeluxe.co.uk]. Please provide your proof of purchase, a detailed description of the issue, and, if possible, photographs.

A valid proof of purchase, such as a sales receipt or invoice, is required for any claims under this quarantee.

Limitations:

The total liability of the retailer or manufacturer under this guarantee is limited to the purchase price of the furniture.

Expiry of Guarantee:

This guarantee expires after the specified 2-year period, and no claims will be accepted beyond this timeframe.

Discretionary Changes:

The retailer or manufacturer reserves the right to make changes or modifications to the terms and conditions of this guarantee with notice to the consumer.

Resolution:

Depending on the nature of the issue, we will either repair or replace the defective part or product at our discretion.

We may use similar materials if the original ones are unavailable. If a frame repair requires fabric replacement, it might not be an exact match, but we'll try to find a close alternative. If your product can't be repaired, we'll replace it with the same model. If that's not possible, we'll provide a substitute with a similar specification or value.

Our guarantee does not extend to::

Evidence of product abuse, misuse, or usage in non-domestic environments.

Natural wear and tear, inclusive of scratches and surface chips. Products that have not been adequately maintained by care instructions.

Any alterations or repairs performed by parties other than ourselves. Fading, cracking, and timber splitting due to the natural aging process from weathering.

Products in an unsanitary condition, such as those affected by pet-related issues. We reserve the right to decline collection and/or disposal of unsanitary products.

Products exported outside of Great Britain and Northern Ireland.

Terms and Conditions:

This guarantee is valid only for the original purchaser and is non-transferable.

Any modifications or repairs not authorized by Finn Deluxe will void the guarantee.

The guarantee does not cover incidental or consequential damages.

∰ FINN DELUXE®

FURNITURE & HOME ACCESSORIES

Please be aware that variations in color may occur as technolgcial factors of the printing process. The specifications, models, and images shown in this catalog are subject to change and may include errors or inaccuracies. We reserve the right to modify dimensions, materials, and designs at any time.

All rights reserved.

www.finndeluxe.co.uk

Trident Court, 1 Oakcroft Road, Chessington, Surrey, KT9 1BD United Kingdom

Tel: +(0)7436 193624 sales@finndeluxe.co.uk